
 Indicates fold in Hi-Tuff Unsupported Membrane

 Indicates cut in overlapping primary Hi-Tuff Membrane

- Notes:
1. Perimeter membrane fastening should be started within 15 cm (6") of corner.
 2. If using Un-Reinforced Flashing, cut square piece with rounded corners approximately 15cm (6") square.



Option 2 - Outside Corners

ROOFING SYSTEMS DETAIL

Scale:
Date: 20/10/2023
Detail no.: H-S-303-2